



INSTRUCTION SHEET

POSITION SPACER BETWEEN FRAME AND IDLER ARM BRACKET




© COPYRIGHT 1992 / REVISED AUGUST, 1992 / LITHO U.S.A.



PLACER LA CALE ENTRE LE CADRE ET LE SUPPORT DU BRAS DE RENVOI

FEUILLET D'INSTRUCTIONS

IMPRIMÉ 3976



SITÚE EL SEPARADOR ENTRE EL ARMAZÓN Y EL APOYO DEL BRAZO LOCO

HOJA DE INSTRUCCIONES

FORMULARIO 3976